

ASSEMBLY INSTRUCTIONS

RETROFIT COMPONENT „TRIPLE LOCK SLEEVE“ FOR EDELRID TREEREX TREE CARE HARNESS



1. Open triple lock buckle



2. Remove the sticker with a flat tool (e.g. screwdriver)



3. Peel off sticker



4. Slide retrofit component Triple Lock-Sleeve over the buckle



5. Engage triple lock sleeve



6. Check triple lock sleeve for tight fit



7. A total of three buckles, the hip belt buckle and the two leg loop buckles, would need to be upgraded.

